

A diagram of a rectangular box. Inside the box, there are two dots. A line segment connects the top dot to the top edge of the box.

A diagram of a square electrical panel. It features a central rectangular switch with two horizontal slots. The panel is secured by four screws, one in each corner. A vertical line passes through the center of the panel, with a small dot above and below the switch.

(REP.-KIT)

LOUDSPEAKER	LA 12" AUS SX 300DL 123SX	358 288	(453 348)
HORN	HPT 94	357 979	
DRIVER	DH 2010 A	353 078	(450 010)

Ausgabe	Änderung	Tag	Name

2000	Tag	Name
Bearb.	30.8.	P. Kaiser
Gepr.		
Stand	14.9.00	P. Kaiser

**EV***AUDIO*  
**DYNACORD**

## SERVICE-INFORMATION

Maßstab

358	439
-----	-----

MX 12

4-